

188 MAX LUMENS

E2


GEN 2
KEYCHAIN LIGHT

INCLUDES

- E2 FLASHLIGHT
- POCKET CLIP
- SPARE O-RINGS
- INSTRUCTION MANUAL

BATTERIES

1 x AA
(NOT INCLUDED)



The newly redesigned push button E2 produces an amazing 188 lumens with 2 levels of brightness and strobe. This compact keychain light can also be used as a great everyday carry pocket light. Its compact size and lightweight design makes it a solid competitor in its category.

LED Type:	CREE XP-G2 R5 White LED		
Battery:	(1) AA Battery (Not Compatible with Li-ion)		
Size:	Length: 87.5 mm		
	Bezel Diameter: 18.2 mm		
	Body Diameter: 18.2 mm		
Weight:	34g (without battery)		
Illumination:	188 Lumens	55 Lumens	188 Lumens (Strobe)
	1.3 hrs	3.9 hrs	2.6 hrs

INTRODUCTION

The Powertac E2 has been redesigned with all new specs. It has been fitted with the new CREE XP-G2 R5 LED which gives it a maximum output of 188 Lumens. A push button tail switch makes it very easy to use. The first choice by many who seek a small compact keychain light that uses a single AA battery. Its easy to carry and will provide peace of mind knowing the ultimate keychain light will always be ready to use. The E2 is in a class of its own. With a NO HASSLE lifetime warranty to back it up, it becomes an easy choice.


USAGE INSTRUCTIONS

1. To install battery: Remove bezel head and insert one AA battery into the body tube with the anode (+) facing toward the flashlight head. Re-attach and tighten bezel head



2. To turn the light ON: Push the back switch to click.

3. To switch light levels: Half press the back switch to change light levels.



DISCLAIMER

- After long periods of use on the highest setting, the surface area may get hot. Please use caution when using the flashlight in a constant high brightness level. It is recommended to let the flashlight cool down to prevent any injury.
- High intensity light is harmful to human eyes. This product is not meant to be handled by children under the age of 18 without adult supervision.
- Use the highest quality, protected-circuit batteries to insure maximum performance and safety. Consult with the manufacturer regarding any questions or concerns.
- PowerTac's liability is voided if the light is not used in a proper manner or if modified.
- PowerTac reserves the right to change the design and/or specifications of all PowerTac products without prior notice.
- Please do not change batteries at dangerous locations such as gas stations. Batteries must only be changed or removed when light is off.
- Do not use or attempt to recharge a disposable CR123 battery! Do not throw the flashlight into a fire as an explosion may occur.

THE POWERTAC NO-HASSLE LIFETIME WARRANTY

PowerTac warrants our illumination tools to be free from defects in workmanship and materials, including any LEDs housed within, for the lifetime of the original parts (the lifetime of the parts are specified by individual parts manufacturers). We will repair or replace your original purchase of these products, at our discretion, if it is determined by us to be defective. Electronics, chargers, and rechargeable batteries are covered for a period of two years with proof of purchase. Normal wear and tear – including lamps burning out, batteries draining, and switches wearing out – is not covered, nor is damage resulting from misuse, abuse, neglect, battery damage, use of other non-approved batteries or altering these products from their original state. Parts and accessories for illumination tools are not covered by this warranty